

CONSTRUCTION DETAILS

- D. Install handhole.
- E. Install 3" polyvinyl chloride electrical conduit (Schedule 80) (trenched).
- G. Install 4" polyvinyl chloride electrical conduit (Schedule 80) (bored).
- H. Install 3" polyvinyl chloride electrical conduit (Schedule 80) (bored).
- L. Non-Invasive probe set with 1000' lead in.
- Q Install ground mounted sign and supports.
- V. Non-Invasive probe set with 500' lead in.
- W. Replace existing pole mounted signs with an S5-1 sign as shown.

